



information@dramm.com www.dramm.com

## Machine operations

The water Cart is quite simple.

#### To Charge:

1.Place switch in "charge" position.

2.Plug charger in special plug on water Cart Pump/Power box.

3.Plug Charger into 110V wall outlet.

4.when indicator light is green, battery is fully charged.

NOTE: Water cart cannot be operating while charger is attached.

To Operate:

1. Fill unit with desired amount of water.

2. Place switch in "Run" position. (Pump will run momentarily)

3. Place Watering Wand tip in fill opening on top of tank.

4. Squeeze valve on Watering Wand as if to water. Pump will run and push all air out of hose line.

5. Once air is out of hose line you are ready to begin watering.

NOTE: Each time the valve is released the pump will stop pumping. When valve is squeezed as if to water the pump will restart.

The pump stopping and restarting is controlled by a built in preset pressure switch.

Storage: When watering task is completed, wind up hose.

Place switch in center position.

Put machine away or follow recharging instructions.

Make sure water cart is not stored in an area where temperatures go

below freezing.



## **Removing Pump Box from Handle**





Remove Locking screw - When closing box Only hand tighten

Remove Pump Box Cover

Remove 4 box screws

To reassemble just repeat the above in reverse order



## Removing hoses from pump



Pump and hoses assembled



Locate locking pin



Lift locking pin



Remove locking pin

Carefully remove hose & fitting from pump body


To reassemble, carefully re-insert fitting into pump body, insert pin and push down pin to lock in place.



# Wiring Layout







1	D11093B	Cart 20 Gallon	1
2	500006	Wheel 2x10	2
3	500051	Caster Swivel 1x6	2
4	D11096	Handle Assembly	1
5	610020	Tank 20 Gallon	1
6	D11909	Control Box Assembly	1
7	10501	Bulkhead fitting 3/4 FPT	1
8	220108	Elbow 3/4 PT Street PVC	1
9	220004	Hex Nipple 3/4 NY	2
10	220606	Tee 3/4 FPT PVC	1
11	230026	Valve Ball 3/4 Dura PVC	1
12	220203	Barb 3/4x3/4 MPT NY	1
13	250020	3/4"x 27-1/2" Suction Hose	1
14	220402	Clamp Hose 5/16Wx1-1/4H	2
15	D11305	Anti-Vortex	1
16	220019	Bushing 1/2PT x 3/4PG ny	1
17	290004	Filter Inline Viton	1
18	220222	Barb 3/4 x 1/2 FPT NY	1
19	D11098C	Axle MSO 2011	1
	330100	Charger	1

_		-			-		-								_				_			·
	QTY	-	-	-	-	-	-	-	-	-	2	2	-	-	2	-	۲	-	2	-	4	
Water Cart Control Box Assembly	DESCRIPTION	PUMP FLOJET 12V	BATTERY 12V 18A	WC20 BOX	WC20 COVER	RECEPTICLE FEMALE Q-G	NUT-J 1/4-20	THUMB SCREW 1/4-20 × 3/8	PILOT LIGHT RED 12V	HANDLE	HHCS 5/16-18 X 3/4 GR5 z	WASHER LOCK 5/16	NUT SUPPLIED WITH SWITCH	BOOT SWITCH	PORT ADPT 3/4MGH - FLOWJET	ELBOW 3/4PT STREET PVC	ADPT FGH SWVLx3/4FPT BR	BARB 3/4 x 3/4MPT NY	SCREW SHLD #10-24 x 3/8	SWITCH TOGGLE SPDT	EDGING 3 inch each	
					M	R	R				Ŧ			8	8				SC	SV		
	PART NO.	200042	330000	D11907	D11908	C3F	114103	114053	320032	8300875	110021	110321	SWITCH NUT	310102	220027	220108	220025	220203	110500	310005	100100	
	ITEM	-	2	e	4	2	ω	ი	10	1	12			15	16	17	18	19	20	21	22	<i>V</i> I0
		(			(10)			(4)														$\begin{bmatrix} 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 $
																				_		DRA Integrated Plant Health 800.258.0848 information@dramm.com

www.dramm.com